

(2)

(1)

(2)

(3)

Mounting

- A. Mount this page on the back of a board or clip board with this top line (1) parallel with the sighting edge.
- B. Sighting brads may be used at each end of the sighting edge. (2)
- C. Drill a hole or use a tack to hang weight on a string from the point marked +. (3)

Measuring Slope

A calibrated stake should be set at both the top and bottom of the slope to be measured. Sight at a point from the top of one stake to the top of the other stake. Hold the slope finder steady. After sighting, pinch the string against the scale and read the percent slope directly.

